

1,4L-ST



190114

Technical data

Name	Thermo jug 1,4L-ST
Code-No.:	190114
Material:	Stainless steel, plastic
Colour:	Silver, black
Model:	▪ Double walls ▪ Suitable for dishwasher ▪ Lid with pouring mechanism ▪ Temperature loss / hour approx.: 2.6 °C
Capacity:	1.4 litres
Dimensions:	W 140 x D 170 x H 215 mm
Diameter surface:	140 mm
Weight:	0.72 kg

We reserve the right to implement the technical modifications!

Designed for coffee machines:

“Contessa 1002” (Code-No. A190043) / “Contessa Duo” (Code-No. 190049) /
“Aurora 20” (Code-No. 190047)

Instructions and advice



NOTE!

Before each use, thoroughly clean the thermo jug with hot water and a mild cleaning agent. After cleaning, rinse the thermo jug with clear water several times.

- Fill up the thermo jug with hot or cold drink.
- Place the lid and turn it clockwise in order to close it.
- To pour the drink, tilt the thermo jug and press the button on the lid with pouring mechanism. Fill up the cup or glass with a desired amount of drink.
- Close the lid by releasing the button.



- We recommend to pre-heat the thermo jug for warm drinks or cool down for cold drinks in order to maintain the temperature of the drink in the thermo jug for as long as possible. Rinse the interior of the thermo jug with hot or cold water, depending on the drink, or leave the water inside for some time before filling up the thermo jug with a required drink for a longer time. You will achieve the best results by following the method.
- Do not fill up the thermo jug with fizzy drinks, milk drinks or food for infants because a risk of germs or bacteria exists.
- Before filling up the thermo jug with water or tea when there was coffee inside before the thermo jug should be thoroughly cleaned to remove the odour of coffee.

Cleaning

- Clean the thermo jug after each use.
- **Never** use aggressive cleaning agents.
- Always use a soft cloth and **never** use coarse cleaning agents that could damage the surface of the stainless steel thermo jug.
- Remove the lid of the thermo jug for cleaning.
- Clean the thermo jug and the lid with warm water and a mild cleaning agent or in a dishwasher.
- Hard water may leave white, mineral deposits inside the thermo jug. Coffee usually colour the deposits and leave the brownish deposit. In order to remove the deposits use a cleaning agent available on the market. Observe the instructions of the manufacturer of such a cleaning agent.
- After cleaning, rinse the thermo jug with clear water **several times**.
- Wipe the exterior of the thermo jug with a soft, moist cloth.
- After cleaning, leave the thermo jug open to let it dry and store for the next use.

Bartscher GmbH
Franz-Kleine-Str. 28
33154 Salzkotten
Germany

phone: +49 5258 971-0
fax: +49 5258 971-120
Service-Hotline: +49 5258 971-197
www.bartscher.com