



500378

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

Phone: +49 5258 971-0
Fax: +49 5258 971-120
Service hotline: +49 5258 971-197
www.bartscher.com

Version: 3.0

Date of preparation: 2025-10-31

Original instruction manual

Technical Specifications

Name:	Double cereal dispenser
Code-No:	500378
Material:	plastic steel plate, painted
Number of container:	2
Content container in litres:	2 x 3,5
Height of bowls, max. in mm:	75
Dimensions (W x D x H) in mm:	360 x 170 x 395
Weight in kg:	3,7

We reserve the right to make technical changes!

Design / Features

- Designed for:
 - Cornflakes
 - Cereals
 - Musli
 - Nuts
- Properties:
 - Scratch-proof container
 - Suitable for wall mounting
- Not included in delivery:
 - Attachment material

EN

Intended Use

This appliance is only intended for use described in the operating instructions, with the supplied and approved components.

Any other use is considered against the intended purpose. The manufacturer shall not be liable for any damage due to unintended use. In such cases the responsible party shall only be the user/operator.

The following is an intended purpose:

- Portioning of cereals.

Parts identification / Delivery terms




Fig. 1

1. Container (2x)
2. Base
3. Container holder (2x)
4. Container bottom lid (2x)
5. Doser knob (2x)
6. Container lid (2x)
7. Doser (2x)

Unpacking

1. Unpack the cereal dispenser and dispose of all packaging material in accordance with regulations.
2. Check the contents of the delivery.
3. Clean the cereal dispenser according to the instructions in the **"Cleaning"** section.

Assembly / Setting up or hanging up

1. Insert the portioner into the container so that the perforation in the container and the portioner line up.
2. Then insert the pin from the rotary wheel through this connection so that the portioner is securely in place.



Fig. 2

3. Place the rack on a flat, dry surface.
4. Attach the container holder to the frame.
5. Insert the container into the container holder.

NOTE!

Alternatively, the cereal dispenser can be hung on the wall in a suitable location. Use suitable fastening materials (not included in delivery).




Fig. 3

Fill with cereals / remove




Fig. 4

EN

Cleaning

CAUTION!

Never use any type of abrasive cleaner that could scratch the Surface.

Do not clean the individual parts of the cereal dispenser in the dishwasher!

1. Fill the container with desired cereals.
 2. Place the lid on the container.
 3. Place a suitable bowl under the container.
 4. Draw the required amount of cereals by turning the tap clockwise.
Every turn allows for dispensing approx. 50 ml of the cereals.
 5. Before any longer intervals in using the cereal dispenser seal the bottom of the dispenser with the plug to maintain freshness of the cereals.
1. Clean the cereal dispenser regularly.
 2. Remove the individual parts.
 3. Clean the individual parts with warm water, a mild detergent and a soft cloth or sponge.
 4. Rinse with clean water.
 5. Allow the cleaned parts to air dry or dry them with a soft, lint-free cloth.